

All Voters Can Use Accessible Voting Equipment

The ImageCast Evolution

can...

- Read a voter their ballot
- Make text bigger
- Change the contrast of the screen
- Warn a voter if they overvote or skip a contest



Answering Voter Questions

➔ What is the ImageCast Evolution?

The ImageCast Evolution is a machine that lets you make your choices on a touchscreen or with a keypad before printing your selections on your ballot.

➔ How does the ImageCast Evolution help me?

This means you can review the candidates you select and correct any mistakes before your selections are printed.

Accessibility Basics

- Offer the ImageCast Evolution to every voter.
- Give all voters courteous attention in exercising their right to vote.
- Remember, not all disabilities are visible. If an individual requests assistance, trust that it is necessary.
- Be considerate of the extra time it might take for a person with a disability or an elderly person to answer questions and get things done.

All Voters Can Use Accessible Voting Equipment

During an accessible voting session the ImageCast Evolution must provide...

- 27 in. of knee clearance
- 19 in. of toe clearance
- 28-34 in. clear space below the screen
- 30 in. x 48 in. clear space in front of the machine
- Privacy so no one can see how the voter is marking their ballot
- A chair nearby for voters who need it, but not blocking access for a voter using a wheelchair

When the polls open the ImageCast Evolution must be...

- Set up
 - Tactile keypad and headphones are ready to be plugged in
- Turned on
 - Poll workers are available to start an accessible voting session
- Functioning
 - No error messages

A poll worker must be able to...

- Turn on the ImageCast Evolution and start a voting session
- Activate the correct ballot style if necessary
- Explain to a voter how to use the ImageCast Evolution to cast their ballot including adding write-ins
- Change the ink cartridge

If you have questions about how to use the ImageCast Evolution, talk to your clerk or chief inspector or reference the user manual.